

## SAFETY


PLEASE CAREFULLY NOTE THE FOLLOWING

1. WHEN ASSEMBLING, ENSURE RUBBER FEET ARE CORRECTLY ASSEMBLED TO LEGS, AND SECURELY-TIGHTEN ALL BOLT AND SCREW ASSEMBLIES.
2. NEVER EXCEED RECOMMENDED MAXIMUM WEIGHT ON WORK-TOPS.
3. NEVER EXCEED RECOMMENDED MAXIMUM WEIGHT CAPACITY OF WORK-TOPS (100 KG/220LBS) ALWAYS LOWER HEAVY LOADS ONTO WORK-TOPS GENTLY, SO THAT STRAIN IS TAKEN UP GRADUALLY.



#330001

## WORK BENCH
















[www.meridianintl.com](http://www.meridianintl.com)

## ASSEMBLE INSTRUCTION SHEET

TOOLS REQUIRED: 1. SCREWDRIVER(PHILLIPS HEAD NO. 2)  
2. HAMMER

### A. PARTS LIST

NO	FIGURE	DESCRIPTION (MM)	QTY
#1		WORK-TOPS	2PCS
#2		SLIDE BASES	2PCS
#3		BOLTS (HEX)	4PCS
#4		CROSSBARS	2PCS
#5		LEG FRAMES	2PCS
#6		PLASTIC FEET	4PCS
#7		WASHERS 16.0×8×1.2	4PCS
#8		WOOD SCREWS 4.8mm×16mm	16PCS
#9		BOLTS (PHILLIPS) M6×P1.0×37mm	8PCS
#10		NUTS M6×P1.0	8PCS
#11		NUTS M8×P1.2	4PCS
#12		CHOCKS	4PCS
#13		WASHERS 13×6×1.2	8PCS

### B. ASSEMBLY STEPS:


STEP 1: USE BOLTS (# 9) WASHERS (#13) AND NUTS (#10) TO CONNECT CROSSBARS (#4) AND LEG FRAMES (#5)

STEP 2: USE WOODSCREWS (# 8) TO CONNECT SLIDE BASES (#2) AND WORK-TOPS (#1)

STEP 3: FIT LEG FRAMES (#5) INTO SLIDE BASES (#2), LINE UP HOLES IN SLIDE BASE WITH HOLES IN LEG FRAME INSERT BOLTS (#3) AND WASHERS (#7) FROM OUTSIDE OF THE BASE AND ATTACH WASHERS (#7) AND NUTS (#11) FROM INSIDE USE SCREWDRIVER AND SPANNER TO TIGHTEN SCREWS.

STEP 4: ATTACH PLASTIC FEET (#6) TO THE LEGS (#5). EACH FOOT MUST BE ATTACHED WITH LONGEST SIDE TO OUTER CORNER WHICH IS INDICATED BY ARROW INSIDE.

STEP 5: SELECT SUITABLE HOLES ON THE WORK-TOPS TO FIX CHOCKS (# 12)



#### REMARK:

1. DO NOT USE AS LADDER.
- UNSAFE TO STAND ON.
2. LOAD CAPACT MAC 100 KGS